

TORLYS

smart floors

TORLYS EverWood **Vista collection** **(FloorScore-certified)**

PART 1 – MATERIALS

- .1 High-Performance vinyl flooring, consisting of a top 0.3mm transparent vinyl wear layer, a 1.7mm vinyl decorative layer, and a 4.5mm layer of extruded High Density WPC.
- .2 **TORLYS EverWood Vista** flooring shall be:
 - .1 *Size:* 4 7/8" x 48 3/8"(nominal) – 123 mm x 1,230 mm
 - .2 *Total Thickness:* 1/4" (nominal) – 6.5 mm
 - .3 *Type of Finishing:* PUR-coated vinyl
 - .4 *Edge Type:* Bevel 4-sides
 - .5 *Type of Decorative Top Layer:* printed vinyl layer
 - .6 *Assembly System:* Uniclic[®] Glueless
 - .7 *Colours:* As selected by the Architect
 - .8 *Type of Installation:* Floating
- .3 Accessories :
 - .1 TORLYS EverWood Vista Mouldings: As recommended by the manufacturer
 - .2 Colours: As selected by the architect

PART 2 – PACKAGING INFORMATION

- .1 *Pieces per carton:* 11
- .2 *Square metres/Square feet per carton:* 1.664m² / 17.91 sq. ft.
- .3 *Weight per Carton:* 12.7 kg / 28.66 lbs.

PART 3 – EXECUTION

- 3.1 Site Verification of Conditions and Preparation:
 - .1 Repair any defects in the subfloor. All subfloors must be clean, firm, flat (within 3/16" – 4.8mm in 10ft – 3m), dry (less than 3% moisture on concrete, 10% or less on plywood) and smooth. You can lay the planks over any solid and stable subfloor material, including plywood, chipboard, old non-creaking flooring boards, hardwood flooring, concrete slabs, PVC or most ceramic tile (avoid heavily embossed tile). It is essential that the crawl space under wood subfloors is sufficiently ventilated. Remove any obstacles and provide sufficient ventilation.

- .2 Remove existing carpet, baseboards, quarter-rounds and thresholds and undercut door jambs, using a piece of flooring material as a guide. Repair all defects in the sub-floor. Additional expansion can be achieved by undercutting drywall.
- .3 Check that the doors can still open and close after installing the floor.
- .4 Doors may have to be cut to supply sufficient clearance.
- .5 The door jambs may need to be adapted to install the floor under them.
- .6 For aesthetic appearance we suggest that you measure the width of the room to ensure that the width of the pieces of the first and last row is approximately the same and not less than 2" (5cm). Cut the width of the pieces of the first and last row as needed.
- .7 The floor should be installed from several cartons at the same time, shuffling the planks to insure colour and shade mix. If possible, lay the planks parallel to the source of light. The ideal environment is a temperature of 60°F - 70°F (16°C - 21°C).

3.2 Installation

- .1 Prepare the subfloor by covering it with TORLYS VX, LV-Pro, Safe and Sound or CorkPlus underlay . When installing TORLYS EverWood Vista with CorkPlus underlay, first cover the subfloor with 6 mil (0.15mm) poly, overlap the edges by 12" (30cm), damp-proof tape the seams and run the poly 4" (10cm) up on each wall. Note: TORLYS EverWood Vista can also be installed, floating, without any additional underlay.
- .2 A minimum of 1/8" (3.2mm) expansion gap must be provided at all walls, around pipes and at thresholds. These gaps may be covered by a moulding that is not fixed to the TORLYS Everwood Vista floor, but to the wall. Install the planks in the same direction as the longest wall, or the same direction in which the light falls, for a more appealing look. Begin installing the floor from the left corner of the room.
- .3 Detailed installation instructions are included on the packaging and can also be downloaded at www.torlys.com/builder/resources/installation-instructions/
- 4. TORLYS EverWood Vista can also be installed glued-down. Please contact TORLYS for details.

3.3. Cleaning

Dust mop or vacuum regularly to remove loose soil. Clean as required with TORLYS Natural Glow Cleaning Kit. Detailed maintenance information can be accessed at www.torlys.com/builder/resources/product-care/